

## MEDIAR 408 & 608 - 預約設定 Timer

MEDIAR 408 & 608 顯示屏



### 預約設定 Timer

(\* 預約功能是以一天內為單位及單次運作，如設定每天運作，請設定預約一的開機為 23:59 及關機為 00:01，而預約二為您打算設定的時間)

在待機狀態 -> 按預約鍵 (圖案係筆)

- 減時 -> Plasma ion 等離子鍵
- 加時 -> UV 鍵
- 往下一步 -> Speed 風速鍵

例如: 由小時轉去分鐘 & 由 pre-on 轉去 pre-off & 由預約 1 轉去下一個預約  
(暫停預約時，按預約鍵時，圖示 Pre-on ①②③ Pre-off ①②③ 會閃爍)

### 開啓 & 暫停預約

在待機狀態 -> 按 Speed 風速鍵 (圖案係風扇)

	<u>預約開啓 / 使用預約</u>	<u>預約暫停</u>
<u>圖示 icon</u>		
Pre-on ①②③	<u>亮著</u>	<u>閃爍</u>
Pre-off ①②③		

### 查詢預約

在待機狀態 -> 按 Plasma ion 等離子鍵

#### 預約開啓 / 使用預約

會顯示預約的時間

按 Speed 風速鍵，便可以查看下一個 pre-on / pre-off 時間

#### 預約暫停

以下圖示會閃爍 (並不會顯示預約時間)

Pre-on ①②③

Pre-off ①②③

## MEDIAR 408 & 608 - Timer

### MEDIAR 408 & 608 Display



### Setting Timer

(\*The timer function is based on one day and a single operation. If you want to set daily operation, please set the start time of the first timer appointment to 23:59 and the power off to 00:01, while the second timer appointment is the time you want to set)

Standby mode -> Press Timer (The icon is a pen)

- Reduce time -> Press Plasma ion
- Increase -> Press UV
- Go to next step -> Press Speed

Example: When you want to switch from hour to minute, switch from pre-on to pre-off and go to next timer appointment, please press speed. (During suspend timer, the icon Pre-on ①②③ and Pre-off ①②③ will blink when you press timer)

### Start & suspend timer

Standby mode -> Press Speed (The icon is a fan)

	<u>Start timer appointment</u>	<u>Suspend timer</u>
<u>icon</u>		
Pre-on ①②③	<u>Light on</u>	<u>Blink</u>
Pre-off ①②③		

### Inquiry timer appointment

Standby mode -> Press Plasma ion

#### Start timer appointment – show appointment time

Press Speed to check next appointments (pre-on / pre-off)

#### Suspend timer

The following icon will blink and do not show appointment time

Pre-on ①②③

Pre-off ①②③